




Assembly instructions

RE050 RE051 Retractable belt stanchion



The contents of the package:



- A. Chromate pole with retractable belt - 1 piece
- B. Base weight - 1 piece
- C. Chromate cover - 1 piece



- 1. Remove the parts from the packaging and place them on an even surface.
- 2. Place the chromate cover over the base weight, so that the hole in the middle remains free.
- 3. Loosen the screw together with the washer on the chromate pole through counterclockwise rotation.



- 4. Insert the screw into the assembly consisting of chromate cover, base weight and the chromate pole. Tighten the screw through clockwise rotation until it fixes.
- 5. Place the retractable belt stanchion assembled in an upright position.



- 6. Pull out the retractable belt at the top of the pole.
- 7. Attach the belt to the next pole by inserting the plastic end of the retractable belt in one of the 3 free slots. Retractable belt can be locked against accidental belt release by rotating the lower part of the plastic end.

The pictures are for presentation only; your product can be slightly different!